

LE POTATO 2.0®



Installation & Adjustment Guide

Restore the Legendary V-Twin Sound

DISASSEMBLY

Sportster

- Remove the two mounting screws.
- Disconnect the electrical connector.
- Rotate the IAC unit a quarter turn to release it.

Dyna / Softail / Touring

- Lift the fuel tank or remove the air cleaner.
- Disconnect the electrical connector.
- Rotate the IAC unit to release it.

ADJUSTMENT & USE

- Turn knob outward before starting.
- Start engine and warm for 1 minute.
- Adjust gradually for desired idle.

IMPORTANT NOTES

- Do not set low idle on cold engine.
- Allow engine to reach operating temperature.
- Increase idle slightly after long parking.

Engineered for riders who demand authenticity.